

TECH

 **EMC** Insur

ies®

Clearances

Kilns should be located at least 18 inches from noncombustible surfaces and 36 inches from combustible surfaces. Kilns should be placed on noncombustible flooring (i.e., solid masonry or concrete 2 inches thick) extending 12 inches beyond the base of the kiln. When determining clearances, users should remember to allow adequate room for opening, loading, and routine maintenance tasks around the kiln. As always, read and follow manufacturer's recommendations regarding kiln placement.

Continued

